

Codice	Campate	H tot torre	H max p. lavoro	Piani lavoro	Puntoni equilibrio
548HD01C	1	m 1,55	m 0,50	=	==
548HD02C	2	m 2,75	m 1,70	1	==
548HD03C	3	m 3,95	m 2,90	1	==
548HD04C	4	m 5,15	m 4,10	1	==
548HD05C	5	m 6,35	m 5,30	2	4 (mt 2,55)
548HD06C	6	m 7,55	m 6,50	2	4 (mt 2,55)
548HD07C	7	m 8,75	m 7,70	2	4 (mt 2,55)
548HD08C	8	m 9,95	m 8,90	3	4 (mt 2,55)
548HD09C	9	m 11,15	m 10,10	3	4 (mt 2,55)
548HD10C	10	m 12,35	m 11,30	3	4 (mt 2,55)